




18" BUILT IN FREEZER
Right Hand Door Swing

MODELS:

JBZFR18IGX00 (Panel Ready)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10891495	Bracket, Hinge Attach	16		Hinge, Bottom
	W10918236	Use and Care Guide	7	W11205246	Switch, Light		W11036493	Charcoal Sparkle
	W10898660	Energy Guide	8		Trim, Hinge	17	W10141625	Screw
	W10918241	Installation Instructions		W10900024	Charcoal Sparkle	18	W10604160	Clip, Wire
		Tech Sheet	9	2266802	Switch, Power Disconnect	19	W10141645	Screw
	W10918869	English	10	W10882791	Screw	20		Trim, Cabinet Side
	W11108177	French	11	W10897082	Harness, Antenna		W11111409	Ebony (Non-Hinge Side)
2		Cabinet (Not A Serviceable Part)	12	W10678210	Screw (Black)		W11111407	Ebony (Right Hand)
3		Grille	13	W11227357	Tube, Water (Also Order 2300868 - 5/16" Water Connector)	21	W10861217	Module, WIFI
	W10823623	Charcoal Sparkle			Assembly, Grille Mount (Includes Nut)	22		Assembly, Adjustable Toekick
4		Hinge, Top	14				W10848725	Left Hand
	W11240840	Charcoal Sparkle		W11028834	Left Hand		W10848724	Right Hand
5		Assembly, Roller Base		W11028835	Right Hand			
	W10761654	Left Hand	15	W10895127	Cover, Hinge Bracket			
	W10761653	Right Hand						


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10769486	Assembly, Fan	18	W10890824	Harness, Damper	34	W11182410	Assembly, Fill Tube (Includes Heater)
2	W10370680	Fitting, Drain	19	W10826263	Assembly, User Interface	35	2169104	Insulation, Sound Deadening
3	W10816886	Cover, LED Side	20	W10847990	Grille, Air Return	36	W10895218	Cover, Evaporator Panel U Shape
4		Assembly, LED Strip	21		Liner (Not A Serviceable Part)	37	W10895214	Gasket, Evaporator Panel
	W10826246	Left Hand	22	1157158	Screw	38	W10876958	Assembly, Evaporator Cover (Includes Insulation)
	W10901633	Right Hand	23	W10816938	Assembly, Air Tower Panel	39	W10780861	Cover, Evaporator Insulation
5	W10917070	Evaporator	24	W10903460	Light, LED	40		Block, Evaporator Bypass
6	W10225833	Grommet, Motor	25	W11224718	Screw		W11216532	Left Hand
7	12990511	Screw	26	W10909591	Assembly, Icemaker Wire (Includes Thermistor)		W11216529	Right Hand
8	W10816889	Cover, LED Top	27	W10826573	Assembly, Icemaker	41	W10816944	Cover, Manifold
9	W10826247	Strip, Top LED	28		Cover, Icemaker	42		Crossbar, Control
10	W10914639	Assembly, Light Strip		W10880333	Black		W10816922	Upper
11	W11176554	Assembly, Air Tower Gasket (Includes Air Tower)	29		Ladder, Shelf (Includes Screw Guide)		W10887667	Lower
12	W10872906	Assembly, Duct Damper (Includes Heater)		W10905671	Left Hand	43	W10602825	Assembly, Fuse Jumper Wire
13		Assembly, Air Tower Bracket (Includes Rubber Rivets, Washers and Screws)		W10905672	Right Hand	44	W10810633	Harness, Evaporator (Includes Thermistor)
	W11036131	Upper	30	W11084854	Thermistor			
	W11036132	Lower	31	W10912104	Cover, Thermistor			
14	W10816928	Wall, False	32		Screw			
15	W10816934	Duct, Deli		W10894079	Black			
16	W10916552	Gasket, Deli Duct	33	W10826529	Heater, Defrost			
17	W10815187	Assembly, Duct						


FREEZER SHELF PARTS



FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10824593	Assembly, Deli Shelf (Includes Thermistor)	7	W10816763	Assembly, Deli	13	W10875428	Assembly, Ice Bin
2	W11032681	Assembly, Shelf	8		Clip, Retainer	14	W11265008	Thermistor (Includes Cover)
3	W10824119	Assembly, Upper Crisper Slide Support		W10856559	Left Hand	15	W10914639	Assembly, Light Strip
4	W10821600	Assembly, Lower Crisper Slide Support		W10856558	Right Hand	16	W10903460	Light, LED
5	W10816844	Assembly, Crisper	9	W10824232	Assembly, Deli Slide Support	17	W11238953	Harness, Mullion
6	W10816832	Assembly, Ice Crisper	10	W11047771	Housing, Crisper Thermistor	18	W10902247	Plate, Crisper LED Support
			11	W10909589	Harness, Crisper LED	19	W11045476	Bracket, Support
			12	W10605575	Sidearm, Shelf	20	W10882791	Screw


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10823677	Assembly, Freezer Door	6		Assembly, Panel Adjuster	10	W10895136	Cap, Panel Adjust Trim
2	W10824621	Assembly, Door Bin		W10873319	Horizontal			FOLLOWING PARTS NOT ILLUSTRATED
3		Gasket, Door		W11215289	Vertical			
	W11038430	Black	7	W11105109	Trim, Panel Adjust		W11028745	Gauge, Door
4	W10908496	Bracket, Air Divider	8	W11105107	Bracket, Panel Adjust			
5	W10908495	Divider, Air	9	W11085874	Screw			


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Cover Plate	9	W10624574	Supply, Power	19	W11043306	Control, Electronic
	W10823654	Charcoal Sparkle	10	W11110768	Assembly, WIFI Module	20	W10909108	Control, Electronic (LED Driver)
2		Cap, Water Filter			(Also Order 2300868 - 5/16" Water Connector)	21	W10890820	Harness, HV
	W10813884	Grey				22	W10890821	Harness, LV
3	W10680605	Filter, Water				23	W10910459	Tray , Control Board Mounting
4	2223913	Clip	11	W10909588	Cord, Power	24	W10822213	Lid, Cover
5	W10873611	Harness, Valve (Also Order 2300868 - 5/16" Water Connector)	12	2203075	Spacer			
			13	W11168732	Screw			
6	W11248444	Latch, Push	14	W11040337	Assembly, Filter (Also Order 2300868 - 5/16" Water Connector)			
7	W11165806	Housing, Water Filter (Also Order 2300868 - 5/16" Water Connector)	15	W11050485	Tube, Filter Inlet			
			16	W10826558	Mount, Filter			
8	W10869169	Valve, Single Solenoid (Also Order 2300868 - 5/16" Water Connector)	17	W10826572	Cover, Filter Mount			
			18	W10882791	Screw			

LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11235263	Assembly, Compressor Cover	10	489473	Screw	20	W10762098	Condenser (Includes Drain Pan Heater)
2	W10761666	Pan, Base	11	W10801052	Assembly, Condenser Fan Shroud	21	W10874652	Drier
3	W10141625	Screw	12	W10837048	Tube, Process			FOLLOWING PARTS NOT ILLUSTRATED
4	W10886557	Grommet, Evaporator Tray	13	W11328338	Compressor		978026	Valve, Access (5/16")
5	W10772588	Tube, Suction	14	W10587113	Grommet		876764	Valve, Access (3/16")
6	W10801047	Tray, Evaporator Drain	15	2183042	Grommet			REFRIGERANT CHARGE
7	W10834246	Plate, Bottom	16	2319835	Grommet, Condenser			3.15 oz. (R134A)
8	W11083658	Assembly, Inverter Box	17	W10781987	Assembly, Drain Tube			
9	W10770889	Tube, Discharge	18	W10818556	Harness, Compressor			
			19	W10663674	Bracket, Inverter Mounting			

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		BEZEL TRIM KIT
W11227384		Non Hinge - Left Hand / Hinge - Right Hand
W11227385		Hinge - Left Hand / Hinge - Right Hand
W11227386		Hinge - Left Hand / Non Hinge - Right Hand
		JOIN KIT
W11103738		Hinge - Left Hand / Non Hinge - Right Hand
W11103739		Non Hinge - Left Hand / Non Hinge - Right Hand
W11103740		Non Hinge - Left Hand / Hinge - Right Hand
		MISCELLANEOUS
212643		Sealer, Gum (4 Feet)
479502		Tape, Vinyl (3/4 x 108")
876370		Insulation (2 Pieces, 3" x 24" x 48")
876305		Insulation Kit (14 Pieces, 3" x 24" x 48")
876029		Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
978941		Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
505587		Sealer, Mastic (1 Qt)
503695		Cork, Sealer
20000008		Cleaner, Stainless Steel
542638		Grease, Silicone (1/2 Oz.)
542639		Cement, Alumilastic (1 1/4 Oz.)
833938		Kit, Terminal Connector
8003RP		Kit, Water Inlet TORX SCREW WRENCH
1117510		Torx Key TOUCH-UP PAINT
W10756744		Charcoal Sparkle (.3 oz Touch-up Pen)
W10756745		Charcoal Sparkle (.6 oz Touch-up Bottle With Brush)