




UNDERCOUNTER DISHWASHER

MODELS:

JDTSS244GM0 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W10711884	Screw	11	W10854504	Light Pipe
	W10806906	Installation Instructions	5		Access Panel	12	302868	Screw (Black)
	W11263946	Energy Guide		W10852733	Black	13	304392	Screw
	W11255226	Use & Care Guide	6		Panel, Front (Includes 11 & 14)	14	W10692757	Barrel Nut, Front Panel
	W10914074	Tech Sheet, English		W11292033	Stainless	15	3400071	Screw
	W10914075	Tech Sheet, French	7	W10853886	U-nut			
2		Arm, Hinge	8	W10735304	Insulation, Four Layer			
	8534854	Left Hand	9		Handle Assembly			
	8534853	Right Hand		W11190789	Stainless			
3	W10844384	Barrier, Vapor	10	W10315897	Insulation, Front Panel			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)	4	W10348408	Screw	7	W10462395	Brace, Connector
	W11254948	Black	5	W11251295	Control, Electronic	8	W10462393	Box, Connector
2	W10653840	Latch Assembly (Includes Switch)	6	W10806955	Antenna, Front Console			
3	W10898167	Jumper, 4-wire						


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	4	W10667473	Seal, Door Bottom	6	W10620297	Dispenser Assembly
2	8281217	Screw	5	W11050927	Seal, Console/Door	7	W11302842	Wiring Harness
3	W10712594	Inner Door Assembly						


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	11	8531743	Gasket, Flat	20	W10851721	Nut, Air Assembly
2	W10769066	Inlet, Hose	12	W10195038	Nut, Standpipe			(Also Order Item 19)
3	W10584470	Inlet, Water (Also Order Item 4)	13	W10195036	Float & Retainer Assembly	21	W10673168	Blower Assembly
4	8531323	Gasket	14	W10786175	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	22	W10653323	Nozzle, Airduct
5	W10213825	Nut, Water Inlet (Also Order Item 4)				23	W11288079	Tube, Exhaust
6	371505	Clamp, Hose	15	370445	Clamp, Hose	24	W10653320	Clip, Retainer
7	W10327249	Fill Valve Assembly	16	W10545278	Drain loop with check valve assembly			
8	3390631	Screw	17	W10772907	Vent Hose			
9	W10734532	Switch, Overfill Control	18	W10851715	Outlet, Air Assembly (Also Order Item 19)			
10	W10647205	Housing, Overfill (Also Order Item 11)	19	W10653310	Seal, Rubber			

TUB AND FRAME PARTS




TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681498	Tub Assembly	15	W10190778	Wheel Leg	28	304666	Retainer
2	W10713315	Assembly, Terminal Box	16	W10619352	Leveler, Leg	29	W10750120	Insulation, U-Wrap
3	W10660528	Gasket, Tub	17	3378128	Washer, Pronged Cup	30	W10746772	Sound Insulation, Bottom
4	W10813122	Plug, Tub	18	8270182	Spring, Door Balance	31	W10916847	Wifi Module
5	W10544004	Strike, Latch	19	3400014	Screw, Grounding	32	W10380173	Sound Insulator, Bottom
6	304392	Screw	20	W10653292	Cover, Terminal Box	33	W10696509	Heater Element Assembly
7	W10835073	Seal, Cabinet	21	W10158291	Cable, Door			(Includes Heater Washer & Nut)
8	W10486051	Retainer	22	W10292870	Shield, Thermostat			
9	W10084086	Door Balance Assembly	23	W10309090	Screw			
10	3367670	Screw	24	W10866980	Shield, Tub Sound			
11	8269145	Bracket, Undercounter	25	W10300703	Bracket, Thermostat			
12	3400074	Screw	26	W10195091	Thermostat			
13	W10681564	Support Assembly, Rear	27		Spacer, Tub/Brace			
14	W10348411	Screw		W10195630	Left Hand			
				W10195631	Right Hand			

NOTE: If heater element is removed, it must be replaced.


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645659	Motor (Also Order Items 9 & 11)	7	W10858786	Wash Arm Assembly	14	W10531320	Motor, Drain
2	W10195086	Motor, Isolator	8	W10789806	Filter Cup Assembly	15	8269144	Hose, Drain
3	W10455271	Cover, Outlet	9	W10445975	Hose Assembly (Includes 2 Clamps)	16	W10476221	Disc, Diverter
4	W10455268	Sump With Seal (Also Order Items 9 & 11)	10	W10850356	Motor & Sump Assembly	17	W10849439	Motor, Diverter
5	9741232	Screw	11	W10538166	Grommet	18	8269146	Clamp, Hose
6	W10463906	Screen	12	W10348407	Screw	19	W10723295	Indicator, Optical Wash
			13	W10372113	Tab, Sump	20	W10763498	Clamp, Hose


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)	2	W10327455	Sprayarm, Third Level	4	W10340542	Manifold
			3	3400918	Retainer	5	W10448645	Sprayarm, Upper
						6	W10195690	Bracket, Feed Tube


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10194861	Dishrack, Upper	6	W10195840	Positioner, Adjuster	12	W10194862	Tine, Fold Down
2		Housing, Adjuster (Includes Spring and Lever)	7	W10669975	Cupshelf	13	W10610897	Clip, Stemware
	W10588164	Left Hand	8	9741232	Screw	14	W10082853	Clip, Pivot
	W10588165	Right Hand	9	W10250162	Cover, Adjuster	15	8539102	Positioner, Dual Dishrack
3	W10250160	Clip, Adjuster	10		Track, Assembly	16	8562026	Clip, Cupshelf
4	W10546503	Adjuster Assembly		W11192640	Left Hand	17	W10752617	Clip, Dispenser Guard
5	W10195839	Strap, Tether Adjuster		W11192638	Right Hand	18	W10309090	Screw
			11	W11253315	Handle, Dishrack Front	19	W10473792	Handle, Dishrack Rear

LOWER RACK AND TRACK PARTS



LOWER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10665650	Dishrack, Lower	4	W10056351	Tinerow	7	W10713283	Retainer, Sliding Tine Row
2	W10195416	Wheel & Transport Assembly	5	W10175279	Retainer, Tine Row	8	W10610895	Tine Row, Sliding
3	W10473836	Basket Assembly, Silverware	6	W10473835	Lid, Silverware Basket			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		DRAIN HOSE
	W10712310	12 Ft.
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis
		MOISTURE BARRIER KIT
	4396277	Barrier Kit

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	4396603	Meteorite

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis