




## **30" RISE BUILT-IN ELECTRIC DOUBLE OVEN WITH CONVECTION**

### **MODELS:**

JJW3830IL00 (Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|-----------------------------------|-----------------------------|-----------------|---------------------------------|
| 1                           |                 | Literature Parts              | 10                          | W10655463       | Bracket, Blower (Left)            | 22                          | 7101P633-60     | Screw (Black)                   |
|                             | W11235343       | Guide, Use & Care (Oven)      |                             | W10655462       | Bracket, Blower (Right)           | 23                          |                 | Skin, Control Panel             |
|                             | W11235620       | Instructions, Installation    | 11                          | 4451758         | Block, Foam                       |                             | W11197498       | Stainless                       |
|                             | W11234441       | Guide, Internet Connectivity  | 12                          | W10864102       | Tray, Electronic                  |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED |
|                             | W11235304       | Diagram, Wiring               | 13                          | W10655465       | Chassis, Back Divider             |                             | W11216668       | Harness, Main                   |
|                             | W11284426       | Sheet, Tech                   | 14                          | W10444125       | Chassis, Cover Top Front 30"      |                             | W11216658       | Harness, Signal                 |
| 2                           |                 | Assembly, Control Panel       | 15                          | W10667383       | Chassis, Cover Top Back 30"       |                             | W11219538       | Harness, Door Latch             |
|                             | W11196779       | Stainless                     | 16                          | W10728475       | Gasket, Rubber                    |                             | W10562910       | Harness, EOL                    |
| 3                           | W11281213       | Appliance Manager, Copernicus | 17                          | W10566973       | Harness, Keypad (Left To Center)  |                             | W11234542       | Assembly, Antenna & Housing     |
| 4                           | W10489172       | Screw                         | 18                          | W10524350       | Harness, Keypad (Right To Center) |                             | W11229447       | Jumper TOD                      |
| 5                           | W11200129       | Blower                        |                             |                 |                                   |                             | 4450800         | Screw, Grounding                |
| 6                           | W10351295       | Bumper                        | 19                          | W10568405       | Assembly, Speaker                 |                             | 313438          | Clip, Harness                   |
| 7                           | W10810292       | Shield, WiFi Access           | 20                          | W10668510       | Housing                           |                             | W11132988       | Strap, Lead Ground              |
| 8                           | 7101P426-60     | Screw                         | 21                          | W10575307       | Jumper Harness, Power Supply      |                             | 4448664         | Clamp, Conduit                  |
| 9                           | 7101P434-60     | Screw                         |                             |                 |                                   |                             | W10655464       | Bracket, Harness                |
|                             |                 |                               |                             |                 |                                   |                             | 4454842         | Tie, Cable                      |
|                             |                 |                               |                             |                 |                                   |                             | W10431304       | Bag, Hardware                   |


# OVEN PARTS



# OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-----------------------------|-----------------|----------------------------------|-----------------------------|-----------------|--------------------------------|-----------------------------|-----------------|------------------------------------|
| 1                           | W10318196       | Duct, Chassis Back<br>(Upper)    | 21                          | W10283008       | Chassis, Bottom Duct           | 38                          | W11045086       | Receiver, Slow Close<br>Hinge      |
| 2                           | W11085298       | Tube, Vent                       | 22                          |                 | Trim, Bottom Vent              | 39                          | W11284709       | Assembly, Light<br>(Top)           |
| 3                           | W11044775       | Receiver, Hinge                  |                             | W10327377       | Stainless                      | 40                          | W10169757       | Bulb, Light                        |
| 4                           | W10618102       | Spacer, Base                     | 23                          | W10213759       | Support, Air Channel           | 41                          | W10169756       | Lens, Light                        |
| 5                           | W10618131       | Latch, Motorized                 | 24                          | W10351308       | Spacer, Chassis<br>Bottom Duct | 42                          | W11034940       | Shield, Slow Close<br>Hinge        |
| 6                           | W10904158       | Top, Chassis                     | 25                          | W10863234       | Bracket, Side Cover<br>(Left)  | 43                          | W10846765       | Shield, Outer                      |
| 7                           | W11205574       | Assembly, Oven Light             |                             | W10863233       | Bracket, Side Cover<br>(Right) | 44                          | W10832249       | Shield, Bottom (Left)              |
| 8                           | W10618101       | Foot, Base                       |                             |                 |                                |                             | W10832250       | Shield, Bottom (Right)             |
| 9                           | W10904163       | Deflector, Blower                | 26                          | 8285593         | Cover, Connector               | 45                          | W10834286       | Spacer, Center                     |
| 10                          | W10254050       | Screw                            | 27                          | 7101P426-60     | Screw                          | 46                          | 7101P427-60     | Screw                              |
| 11                          | W10739089       | Gasket                           | 28                          | W10472386       | Lens, Light                    | 47                          | W10791505       | Shield, Front Frame<br>Heat        |
| 12                          | W10616810       | Cover, Vent Exhaust              | 29                          | W10327369       | Cover, Side Trim (Left)        | 48                          | W10618105       | Spacer, Lateral                    |
| 13                          | W10663556       | Side, Chassis<br>(Left)          |                             | W10327368       | Cover, Side Trim<br>(Right)    |                             |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED |
|                             | W10318190       | Side, Chassis<br>(Right)         | 30                          | W10834501       | Spacers, Front                 |                             | W10520715       | Insulation, Wrap                   |
| 14                          |                 | Back, Chassis (Not<br>Serviced)  | 31                          | W10472384       | Bulb, Light                    |                             | W10566640       | Insulation, Cavity                 |
| 15                          |                 | Liner, Oven (Not<br>Serviceable) | 32                          | W10542857       | Duct, Chassis Back<br>(Lower)  |                             | W10464568       | Insulation, Control<br>Knob        |
| 16                          | W11208463       | Probe, Sensor                    | 33                          | W10616809       | Base, Vent Exhaust             |                             |                 |                                    |
| 17                          | W10351278       | Bumper & Screw                   | 34                          | W10904155       | Bracket, U-Shape               |                             |                 |                                    |
| 18                          | 4449751         | Thermostat (TOD)                 | 35                          | W10283040       | Vent, Center 30"               |                             |                 |                                    |
| 19                          | W11238787       | Base, Chassis                    | 36                          | W10283036       | Vent, Top 30"                  |                             |                 |                                    |
| 20                          |                 | Assembly, Bottom<br>Vent         | 37                          | W10618103       | Foot, Front (Left)             |                             |                 |                                    |
|                             |                 |                                  |                             | W10618104       | Foot, Front (Right)            |                             |                 |                                    |
|                             | W10327374       | Stainless                        |                             |                 |                                |                             |                 |                                    |


# UPPER OVEN DOOR PARTS



# UPPER OVEN DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    |
|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|------------------------|-----------------------------|-----------------|-----------------------|
| 1                           | W11213479       | Assembly, Window Pack | 8                           |                 | Assembly, Handle       | 15                          | W10581826       | Bracket, Door (Right) |
| 2                           | W10650497       | Spacer, Handle        |                             | W11251202       | Stainless              | 16                          | W10517428       | Spacer, Vent          |
| 3                           | W10319024       | Washer, Door          | 9                           | W11220347       | Assembly, Glass Cavity | 17                          | W10489273       | Pad, Vent             |
| 4                           | W10549747       | Clip, Spring          | 10                          | 3196183         | Screw                  | 18                          | W11280091       | Vent, Top Metal       |
| 5                           | W10480830       | Screw                 | 11                          | 7101P427-60     | Screw                  |                             |                 |                       |
| 6                           | W11220343       | Hinge, Door           | 12                          | W10517440       | Spacer                 |                             |                 |                       |
| 7                           |                 | Assembly, Door        | 13                          | W10284411       | Screw with Washer      |                             |                 |                       |
|                             | W11199335       | Stainless             | 14                          | W10581831       | Bracket, Door (Left)   |                             |                 |                       |


# LOWER OVEN DOOR PARTS



# LOWER OVEN DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|------------------------|-----------------------------|-----------------|--------------------|
| 1                           | W11213479       | Assembly, Window Pack | 9                           | W11220347       | Assembly, Glass Cavity | 18                          | W11280091       | Vent, Top Metal    |
| 2                           | W10650497       | Spacer, Handle        | 10                          | 3196183         | Screw                  | 19                          |                 | Nameplate          |
| 3                           | W10319024       | Washer, Door          | 11                          | 7101P427-60     | Screw                  |                             | W11238657       | Stainless          |
| 4                           | W10480830       | Screw                 | 12                          | W10581831       | Bracket, Door (Left)   |                             |                 |                    |
| 5                           | W10517440       | Spacer                | 13                          | W10284411       | Screw with Washer      |                             |                 |                    |
| 6                           | W11220343       | Hinge, Door           | 14                          | W10549747       | Clip, Spring           |                             |                 |                    |
| 7                           |                 | Assembly, Door        | 15                          | W10581826       | Bracket, Door (Right)  |                             |                 |                    |
|                             | W11199335       | Stainless             | 16                          | W10517428       | Spacer, Vent           |                             |                 |                    |
| 8                           |                 | Assembly, Handle      | 17                          | W10489273       | Pad, Vent              |                             |                 |                    |
|                             | W11251202       | Stainless             |                             |                 |                        |                             |                 |                    |

# INTERNAL OVEN PARTS



# INTERNAL OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|----------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|--------------------|
| 1                           | W10764078       | Element, Broil             | 11                          | W10663735       | Element, Convection          | 21                          | W10631504       | Nut, Acorn (LH)    |
| 2                           | W11242906       | Rack, Oven                 | 12                          | W10236129       | Screw                        |                             | W10803140       | Nut, Acorn (RH)    |
| 3                           | W10318198       | Tray, Hidden Bake          | 13                          | W10911205       | Shield, Broil Element        | 22                          | W10739592       | Screw              |
| 4                           | 7101P434-60     | Screw                      | 14                          | W10588737       | Shield, Broil Front          |                             |                 |                    |
| 5                           | 7101P426-60     | Screw                      | 15                          | W11252826       | Jack, Meat Probe             |                             |                 |                    |
| 6                           | W10282957       | Crossbar, Hidden Bake Tray | 16                          | W11033111       | Nut, Locking                 |                             |                 |                    |
| 7                           | W10546517       | Element, Bake              | 17                          | W10854021       | Assembly, Convection Element |                             |                 |                    |
| 8                           | W11200176       | Assembly, Convection Motor | 18                          | W11256305       | Rack, Sliding                |                             |                 |                    |
| 9                           | W11313747       | Assembly, Baffle           | 19                          | 9755542         | Probe, Temperature           |                             |                 |                    |
| 10                          | W10853277       | Shield, Convection         | 20                          | W10803141       | Blade, Convection Fan        |                             |                 |                    |

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 72017           | White              |
|                             | 72032           | Black              |

## PAINT, SPRAY

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 285006          | Black              |
|                             | 350938          | Gray Primer        |

## ACCESSORIES

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------------|
|                             | 4396923         | Grid, Broiler Pan and           |
|                             | W10123240       | Rack, Broiler Pan & Roasting    |
|                             | W10355016       | Cleaner, Stainless Steel        |
|                             | W10355049       | Wipes, Stainless Steel Cleaning |

## ADHESIVE

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 482338          | Sealer, Silastic   |