




30" NOIR BUILT-IN ELECTRIC DOUBLE OVEN WITH CONVECTION

MODELS:

JJW3830IM00 (Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10655463	Bracket, Blower (Left)	22	7101P633-60	Screw (Black)
	W11235343	Guide, Use & Care (Oven)		W10655462	Bracket, Blower (Right)			FOLLOWING PARTS NOT ILLUSTRATED
	W11235620	Instructions, Installation	11	4451758	Block, Foam		W11216668	Harness, Main
	W11234441	Guide, Internet Connectivity	12	W10864102	Tray, Electronic		W11216658	Harness, Signal
	W11235304	Diagram, Wiring	13	W10655465	Chassis, Back Divider		W11219538	Harness, Door Latch
	W11284426	Sheet, Tech	14	W10444125	Chassis, Cover Top Front 30"		W10562910	Harness, EOL
2		Assembly, Control Panel	15	W10667383	Chassis, Cover Top Back 30"		W11234542	Assembly, Antenna & Housing
	W11199501	Black	16	W10728475	Gasket, Rubber		W11229447	Jumper TOD
3	W11281213	Appliance Manager, Copernicus	17	W10566973	Harness, Keypad (Left To Center)		4450800	Screw, Grounding
4	W10489172	Screw	18	W10524350	Harness, Keypad (Right To Center)		313438	Clip, Harness
5	W11200129	Blower					W11132988	Strap, Lead Ground
6	W10351295	Bumper	19	W10568405	Assembly, Speaker		4448664	Clamp, Conduit
7	W10810292	Shield, WiFi Access	20	W10668510	Housing		W10655464	Bracket, Harness
8	7101P426-60	Screw	21	W10575307	Jumper Harness, Power Supply		4454842	Tie, Cable
9	7101P434-60	Screw					W10431304	Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10318196	Duct, Chassis Back (Upper)	21	W10283008	Chassis, Bottom Duct	38	W11045086	Receiver, Slow Close Hinge
2	W11085298	Tube, Vent	22		Trim, Bottom Vent	39	W11284709	Assembly, Light (Top)
3	W11044775	Receiver, Hinge		W10327377	Stainless	40	W10169757	Bulb, Light
4	W10618102	Spacer, Base	23	W10213759	Support, Air Channel	41	W10169756	Lens, Light
5	W10618131	Latch, Motorized	24	W10351308	Spacer, Chassis Bottom Duct	42	W11034940	Shield, Slow Close Hinge
6	W10904158	Top, Chassis	25	W10863234	Bracket, Side Cover (Left)	43	W10846765	Shield, Outer
7	W11205574	Assembly, Oven Light		W10863233	Bracket, Side Cover (Right)	44	W10832249	Shield, Bottom (Left)
8	W10618101	Foot, Base					W10832250	Shield, Bottom (Right)
9	W10904163	Deflector, Blower	26	8285593	Cover, Connector	45	W10834286	Spacer, Center
10	W10254050	Screw	27	7101P426-60	Screw	46	7101P427-60	Screw
11	W10739089	Gasket	28	W10472386	Lens, Light	47	W10791505	Shield, Front Frame Heat
12	W10616810	Cover, Vent Exhaust	29	W10327369	Cover, Side Trim (Left)	48	W10618105	Spacer, Lateral
13	W10663556	Side, Chassis (Left)		W10327368	Cover, Side Trim (Right)			FOLLOWING PARTS NOT ILLUSTRATED
	W10318190	Side, Chassis (Right)	30	W10834501	Spacers, Front		W10520715	Insulation, Wrap
14		Back, Chassis (Not Serviced)	31	W10472384	Bulb, Light		W10566640	Insulation, Cavity
15		Liner, Oven (Not Serviceable)	32	W10542857	Duct, Chassis Back (Lower)		W10464568	Insulation, Control Knob
16	W11208463	Probe, Sensor	33	W10616809	Base, Vent Exhaust			
17	W10351278	Bumper & Screw	34	W10904155	Bracket, U-Shape			
18	4449751	Thermostat (TOD)	35	W10283040	Vent, Center 30"			
19	W11238787	Base, Chassis	36	W10283036	Vent, Top 30"			
20		Assembly, Bottom Vent	37	W10618103	Foot, Front (Left)			
				W10618104	Foot, Front (Right)			
	W10327374	Stainless						


UPPER OVEN DOOR PARTS



UPPER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11213479	Assembly, Window Pack	8		Assembly, Handle	15	W10581826	Bracket, Door (Right)
2	W11132942	Spacer, Handle		W11250935	Stainless	16	W10517428	Spacer, Vent
3	W11184524	Washer	9	W11220347	Assembly, Glass Cavity	17	W10489273	Pad, Vent
4	W10549747	Clip, Spring	10	3196183	Screw	18	W11280091	Vent, Top Metal
5	488130	Nut	11	7101P427-60	Screw	19	W10319024	Washer, Door
6	W11220343	Hinge, Door	12	W10517440	Spacer	20	W10284278	Rail, Door Side (Left)
7		Assembly, Door	13	W10284411	Screw with Washer	21	W10284279	Rail, Door Side (Right)
	W11238536	Stainless	14	W10581831	Bracket, Door (Left)			


LOWER OVEN DOOR PARTS



LOWER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11213479	Assembly, Window Pack	9	W11220347	Assembly, Glass Cavity	18	W11280091	Vent, Top Metal
2	W11132942	Spacer, Handle	10	3196183	Screw	19	W10319024	Washer, Door
3	W11184524	Washer	11	7101P427-60	Screw	20	W10284278	Rail, Door Side (Left)
4	488130	Nut	12	W10581831	Bracket, Door (Left)	21	W10284279	Rail, Door Side (Right)
5	W10517440	Spacer	13	W10284411	Screw with Washer			
6	W11220343	Hinge, Door	14	W10549747	Clip, Spring			
7		Assembly, Door	15	W10581826	Bracket, Door (Right)			
	W11199290	Stainless	16	W10517428	Spacer, Vent			
8		Assembly, Handle	17	W10489273	Pad, Vent			
	W11250935	Stainless						

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10764078	Element, Broil	11	W10663735	Element, Convection	21	W10631504	Nut, Acorn (LH)
2	W11242906	Rack, Oven	12	W10236129	Screw		W10803140	Nut, Acorn (RH)
3	W10318198	Tray, Hidden Bake	13	W10911205	Shield, Broil Element	22	W10739592	Screw
4	7101P434-60	Screw	14	W10588737	Shield, Broil Front			
5	7101P426-60	Screw	15	W11252826	Jack, Meat Probe			
6	W10282957	Crossbar, Hidden Bake Tray	16	W11033111	Nut, Locking			
7	W10546517	Element, Bake	17	W10854021	Assembly, Convection Element			
8	W11200176	Assembly, Convection Motor	18	W11256305	Rack, Sliding			
9	W11313747	Assembly, Baffle	19	9755542	Probe, Temperature			
10	W10853277	Shield, Convection	20	W10803141	Blade, Convection Fan			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black

PAINT, SPRAY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	285006	Black
	350938	Gray Primer

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning

ADHESIVE

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic