




NOIR 30" MICROWAVE / WALL OVEN COMBO WITH CONVECTION

MODELS:

JMW2430IM01 (Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	11	4451758	Block, Foam	22	W10524350	Harness, Keypad (Right To Center)
	W11235342	Guide, Use & Care (Oven)	12	W10655465	Chassis, Back Divider			FOLLOWING PARTS NOT ILLUSTRATED
	W11235344	Guide, Use & Care (Oven/Micro Combo)	13	W10318158	Chassis, Cover Top Front 30"		W11216677	Harness, Main
	W11235622	Instructions, Installation	14	W10588732	Chassis, Cover Top Back 30"		W10874059	Harness, Fan & Turntable
	W11284425	Sheet, Tech (Oven/Micro Combo)	15	W10655467	Chassis, Combo Side		W10874060	Harness, Inverter
	W11235300	Diagram, Wiring	16		Assembly, Control Panel (Includes Overlay)		W11216660	Harness, Signal
2	W10568405	Assembly, Speaker		W11241531	Black		W11218145	Harness, Communication
3	W11281214	Appliance Manager, Copernicus	17	W10444127	Cover, 30" Compliment		W11219538	Harness, Door Latch
4	7101P633-60	Screw (Black)	18	W10566973	Harness, Keypad (Left To Center)		W11198503	Jumper Harness, Communication
5	W11200129	Blower	19	W10681157	Cover, Combo Blower		W10889134	Harness, Cable Tree Assembly
6	W10489172	Screw	20	W10575307	Jumper Harness, Power Supply		W11226264	Strap, Ground
7	W10260060	Board, Power Supply	21	W10668510	Housing		4450800	Screw, Grounding
8	7101P426-60	Screw					4448664	Clamp, Conduit
9	7101P434-60	Screw						
10	W10655463	Bracket, Blower (Left)						
	W10655462	Bracket, Blower (Right)						


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8285593	Cover, Connector	16	W11208463	Probe, Sensor	29	W10681156	Deflector, Chassis
2	W11085298	Tube, Vent	17	W10472384	Bulb, Light	30	W10347649	Spacers, Front
3	W11044775	Receiver, Hinge	18	4449751	Thermostat (TOD)	31	W11037653	Cover, Combo Chassis Back Duct (With Hole)
4	W10618102	Spacer, Base	19	W11238787	Base, Chassis	32		Trim, Side
5	W10618131	Latch, Motorized	20		Assembly, Bottom Vent		W10344483	Black (Left)
6	W10904158	Top, Chassis		W10327374	Stainless		W10344482	Black (Right)
7	W11205574	Assembly, Oven Light	21	W10283008	Chassis, Bottom Duct	33	7101P427-60	Screw
8	W10283021	Support, Base (Right)	22	W10283020	Support, Base (Left)	34	W10254050	Screw
9	W10904163	Deflector, Blower	23	W10213759	Support, Air Channel			INSULATION
10	W11299322	Vent, Center 30"	24	W10351308	Spacer, Chassis Bottom Duct		W10520715	Insulation, Wrap
11	W10739089	Gasket	25	W10351278	Bumper & Screw		W10282944	Insulation, Cavity
12	W10616810	Cover, Vent Exhaust	26	W10472386	Lens, Light			
13	W10318190	Side, Chassis	27	7101P426-60	Screw			
14	W10904160	Back, Chassis	28	W10616809	Base, Vent Exhaust			
15		Liner, Oven (Not Serviceable)						


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11213479	Assembly, Window Pack	8		Assembly, Handle	15	W10581831	Bracket, Door (Left)
2	W11132942	Spacer, Handle		W11250935	Stainless	16	W10581826	Bracket, Door (Right)
3		Assembly, Door	9	W11220347	Assembly, Glass Cavity	17	W10517428	Spacer, Vent
	W11213907	Stainless	10	W10319024	Washer, Door	18	W10489273	Pad, Vent
4	W11184524	Washer	11	7101P427-60	Screw	19	W11280091	Vent, Top Metal
5	488130	Nut	12	W10517440	Spacer	20	W10284278	Rail, Door Side (Left)
6	W11220345	Hinge, Door	13	W10284411	Screw with Washer	21	W10284279	Rail, Door Side (Right)
7	3196183	Screw	14	W10549747	Clip, Spring			

INTERNAL OVEN PARTS




INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10764078	Element, Broil
2	W11242906	Rack, Oven
3	W10318198	Tray, Hidden Bake
4	7101P434-60	Screw
5	7101P426-60	Screw
6	W10282957	Crossbar, Hidden Bake Tray
7	W10546517	Element, Bake

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W11256305	Rack, Sliding
9	W10722667	Fan, Convection
10	W10631503	Blade, Fan
11	W10631504	Nut, Acorn (LH)
12	W10521808	Cover, Baffle
13	W11252826	Jack, Meat Probe
14	W11033111	Nut, Locking
15	W11192519	Baffle, Bow Tie

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	9755542	Probe, Temperature
17	W10588738	Shield, Broil Front
18	W10546519	Element, Convection
19	W10720084	Screw
20	W10739592	Screw
21	W10911205	Shield, Broil Element


CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11289988	Manager, Microwave Appliance	14	461967754821	Duct, Magnetron	29	461967750494	Support
2	461967017491	Trim, Side (Left)	15	W10330566	Switch	30	461967750483	Arm, Sliding
3	461967017481	Trim, Side (Right)	16	8205683	Holder, Switch	31	W10460457	Sensor, Humidity
4	461968973241	Vent, Top Microwave	17	423107022541	Reflector	32	461967510191	Bushing
5	W10692851	Filter, Noise	18	423107720491	Lens, Lamp	33	423107845441	Sensor, Convection
6	461967848621	Transformer, Light (20V)	19	461967010591	Clip, Spring	34	461967001792	Fan, Convection
7	241908600053	Fuse	20	W10720308	Harness, Interlock	35	461967848711	Heater, Convection Element
8	4375231	Block, Fuse	21	461967008461	Support, Bottom	36	461967848251	Motor, Convection Fan
9	461967846741	Thermostat, Magnetron	22	W11256757	Hinge, Door	37	241960100002	Sensor, Temperature
10	W11226473	Magnetron	23	W11131760	Assembly, Cooling Fan	38	461967842541	Thermoactuator
11	W10465869	Spring, Lamp	24	W11237240	Inverter	39	W10769147	Sealing, Lamp
12	W10490593	Holder, Lamp	25	461967825971	Screw	40	423107570871	Spring, Release Rod
13	W10795595	Lamp, Halogen	26	W10120235	Rod, Release	41	461967825321	Screw
			27	W10128850	Assembly, Sliding Arm	42	461967825781	Screw (Shoulder)
			28	461967570351	Spring, Torsion			


INTERNAL MICROWAVE PARTS



INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461967721091	Turntable	6	461967848971	Motor, Turntable	11	W10387651	Element, Grill
2	W10367316	Ring, Turntable	7	461968977491	Plate, Crisp	12	461967753871	Support, Element
3	W10545578	Drive, Turntable	8	461968929542	Handle, Pan	13	252262898008	Support, Spring Lock Grill
4	461967451001	Plate, Cover	9	W10748279	Rack, Low Convection			
5	461967753742	Adapter, Turntable Motor	10	W10748280	Rack, High Convection			


TOP VENTING PARTS



TOP VENTING PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	7101P060-60	Screw	7	W10519707	Cover, Back Duct	10	W10710302	Rail, Side (Left)
2	4454949	Holder, Fuse	8	W10655466	Chassis, Combo Side (Left)	11	W10283024	Side, Bracket
3	7101P426-60	Screw		W10283029	Chassis, Combo Side (Right)	12	7101P633-60	Screw (Black)
4	8285593	Cover, Connector	9	W10283022	Support, Crossbar			
5	W10710309	Rail, Side (Right)						
6	W10017410	Fuse, Time Delay						

MICROWAVE DOOR PARTS



MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8304588BL	Cap, Screw	6		Assembly, Outer Door	8	488130	Nut
2	W10359769	Foam, Door Handle		W11198720	Stainless	9	W11184524	Washer
3	W10687342	Assembly, Inner Door	7		Assembly, Handle			
4	7101P338-60	Screw		W11250935	Stainless			
5	W11132942	Spacer, Handle						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
	W10123240	Rack, Broiler Pan & Roasting
	W10355016	Cleaner, Stainless Steel
	4396923	Grid, Broiler Pan and
	8205262RB	Steamer, Microwave