




**UNDERCOUNTER DISHWASHER
(Fingerprint Resistant)**

MODELS:

MDB4949SHZ0 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Panel Front (Also Includes Item 6)	11		Access Panel
	W10806906	Installation Instructions		W11202764	Stainless		W10526114	Black
	W11236381	Energy Guide	5	W10463662	Spacer, Control Bracket Panel	12	3400071	Screw
	W11174463	Use & Care Guide				13	W10518815	Insulation, Four Layer
	W10867183	Tech Sheet, English	6	W10612925	Badge			
	W10867186	Tech Sheet, French	7	W10073520	Insulation, Door			
2		Arm, Hinge	8		Fastener			
	8534854	Left Hand		W10503548	Black			
	8534853	Right Hand	9	W10641745	Bracket, Control			
3	W10844384	Barrier, Vapor	10	302868	Screw (Black)			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	5	W11233967	Clip, Control	9		Handle
	W11133139	Stainless	6	W10348408	Screw (Long)		W11133235	Black
2	W10792164	Jumper, 4 wire						
3	W11168783	Control, Electronic	7	W10825369	Brace, Connector			
4	W10653840	Latch Assembly (Includes Switch)	8	W10825638	Box, Connector			

INNER DOOR PARTS




INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	8281217	Screw
3	W10712597	Inner Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10667473	Seal, Door Bottom
5	W10834758	Wiring Harness

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10620296	Dispenser Assembly
7	W10195007	Seal, Console/Door


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	8	304392	Screw	15	W10195036	Float & Retainer Assembly
2	W10769066	Inlet, Hose	9	370445	Clamp, Hose	16	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
3	W10195536	Inlet, Water (Also Order Item 4)	10	W10545278	Drain loop with check valve assembly			
4	8531323	Gasket	11	W10734532	Switch, Overfill Control			
5	W10213825	Nut, Water Inlet (Also Order Item 4)	12	W10647205	Housing, Overfill (Also Order Item 13)			
6	371505	Clamp, Hose	13	8531743	Gasket, Flat			
7	W10327249	Fill Valve Assembly	14	W10195038	Nut, Standpipe			


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681492	Tub Assembly (Includes Heater Assembly)	10		Tub Spacer	22	W10292870	Shield, Thermostat
				W10195630	Left Hand	23	W10866978	Shield, Tub Sound
				W10195631	Right Hand	24	W10300703	Bracket, Thermostat
2	9743002	Gasket, Mounting Bracket	11	3400074	Screw	25	W10195091	Thermostat
3	W10660528	Gasket, Tub	12	W10348411	Screw	26	W10544004	Strike, Latch
4	W10813122	Plug, Tub	13	W10190778	Wheel Leg	27	3378128	Washer, Pronged Cup
5	W10078083	Wheel And Mount Assembly	14	W10619352	Leveler, Leg	28	304392	Screw
			15	8269145	Bracket, Undercounter	29	W10309090	Screw
6	W10835073	Seal, Cabinet	16	8270020	Spring, Door Balance	30	W10696509	Heater Element Assembly
7	W10713315	Assembly, Terminal Box	17	3367670	Screw			(Includes Heater Washer & Nut)
			18	3400014	Screw, Grounding			NOTE: If heater element is removed, it must be replaced.
8	W10084086	Door Balance Assembly	19	W10653292	Cover, Terminal Box			
			20	W10158291	Cable, Door			
9	W10819539	Sound Insulation, Bottom	21	W10681564	Support Assembly, Rear			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10591545	Accumulator Assembly	10	W10372113	Tab, Sump	20	W10723295	Indicator, Optical Wash
2	W10195086	Motor, Isolator	11	W10348407	Screw	21	W10591575	Capacitor
3	W10736968	Cover, Accumulator	12	W10591570	Sump & Motor Assembly	22	370445	Clamp, Hose
4	W10482462	Sump With Seal (Also Order Items 13 & 18)	13	W10538166	Grommet	23	W10618403	Housing, Pump (Also Order Items 13 & 18)
5	W10463892	Cover, Outlet	14	8533949	Nut	24	W10467002	Screw
6	W10591547	Protector, Inlet	15	W10348269	Pump, Drain	25	W10169167	Clamp, Hose
7	W10591540	Adapter, Drain	16	W10591561	Enclosure, Motor	26	W10605800	Sprayarm, Lower
8	W10591562	Chopper Assembly	17	8269144	Hose, Drain	27	W10710432	Shield, Capacitor
9	W10591569	Motor Assembly (Also Order Item 13)	18	W10445975	Hose Assembly (Includes 2 Clamps)			
			19	W10591558	Impeller Assembly			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)	2	W10327455	Sprayarm, Third Level	4	W10571949	Manifold
			3	3400918	Retainer	5	W10605345	Sprayarm, Upper
						6	W10195690	Bracket, Feed Tube


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10889618	Dishrack, Upper	4	W10306230	Spacer, Track	6	W10082860	Stop, Track (Non-Removable)
2	W10630200	Cupshelf	5	8565925	Stop, Track (Non-Removable)	7	3385089	Track, Dishrack
3	W10571738	Wheel Assembly, Stationary						

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525642	Dishrack, Lower	3	W10630199	Silverware Basket Assembly	4	W10630198	Lid, Side
2	W10195416	Wheel & Transport Assembly				5	W10630197	Lid, Center

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171657	Black
	8171656	White
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		Handle Assembly
	W10702080	Black
	W10702081	White
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis