




UNDERCOUNTER DISHWASHER
Fingerprint Resistant

MODELS:

MDB7959SHZ1 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	W10803537	Stiffener, Door	9	W10641745	Bracket, Control
	W10806906	Installation Instructions	4		Panel Front (Includes Items 6 & 8)	10	302868	Screw (Black)
	W11236381	Energy Guide		W11333805	Stainless	11		Access Panel
	W11172665	Use & Care Guide	5	W10853886	U-nut		W10852733	Black
	W11290951	Tech Sheet	6	W10854504	Light Pipe	12	3400071	Screw
2		Arm, Hinge	7	W10315897	Insulation, Front Panel	13	W10518815	Insulation, Four Layer
	8534854	Left Hand	8	W10692757	Barrel Nut, Front Panel			
	8534853	Right Hand						


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	5	W11233967	Clip, Control	7	W10825369	Brace, Connector
	W11132774	Black	6	W10348408	Screw	8	W10825638	Box, Connector
2	W10566919	Jumper, 4 Wire			(Long)			
3	W11168783	Control, Electronic						
4	W10653840	Latch Assembly (Includes Switch)						

INNER DOOR PARTS




INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	8281217	Screw
3	W10712597	Inner Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10667473	Seal, Door Bottom
5	W10834758	Wiring Harness

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10620296	Dispenser Assembly
7	W11050927	Seal, Console/Door


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	8	304392	Screw	15	W10195036	Float & Retainer Assembly
2	W10769066	Inlet, Hose	9	370445	Clamp, Hose	16	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
3	W10195536	Inlet, Water (Also Order Item 4)	10	W10545278	Drain loop with check valve assembly			
4	8531323	Gasket	11	W10734532	Switch, Overfill Control			
5	W10213825	Nut, Water Inlet (Also Order Item 4)	12	W10647205	Housing, Overfill (Also Order Item 13)			
6	371505	Clamp, Hose	13	8531743	Gasket, Flat			
7	W11130743	Fill Valve Assembly	14	W10195038	Nut, Standpipe			


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681492	Tub Assembly (Includes Heater Assembly)	11	3400074	Screw	26	W10544004	Strike, Latch
2	W10750120	Insulation, U-Wrap	12	W10348411	Screw	27	3378128	Washer, Pronged Cup
3	W10660528	Gasket, Tub	13	W10190778	Wheel Leg	28	304392	Screw
4	W10813122	Plug, Tub	14	W10619352	Leveler, Leg	29	W10681564	Support Assembly, Rear
5	W10486051	Retainer	15	8269145	Bracket, Undercounter	30	W10696509	Heater Element Assembly
6	W10835073	Seal, Cabinet	16	8270020	Spring, Door Balance			(Includes Heater Washer & Nut)
7	W10713315	Assembly, Terminal Box	17	3367670	Screw			NOTE: If heater element is removed, it must be replaced.
8	W10084086	Door Balance Assembly	18	3400014	Screw, Grounding			
9	W10819539	Sound Insulation, Bottom	19	W10653292	Cover, Terminal Box			
10		Tub Spacer	20	W10158291	Cable, Door			
	W10195630	Left Hand	21	304666	Retainer			
	W10195631	Right Hand	22	W10292870	Shield, Thermostat			
			23	W10866980	Shield, Tub Sound			
			24	W10300703	Bracket, Thermostat			
			25	W10195091	Thermostat			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10591545	Accumulator Assembly	10	W10372113	Tab, Sump	20	W10723295	Indicator, Optical Wash
2	W10195086	Motor, Isolator	11	W10348407	Screw	21	W10591575	Capacitor
3	W10736968	Cover, Accumulator	12	W10591570	Sump & Motor Assembly	22	370445	Clamp, Hose
4	W10482462	Sump With Seal (Also Order Items 13 & 18)	13	W11182008	Grommet	23	W10618403	Housing, Pump (Also Order Items 13 & 18)
5	W10463892	Cover, Outlet	14	8533949	Nut	24	W10467002	Screw
6	W10591547	Protector, Inlet	15	W10348269	Pump, Drain	25	W10169167	Clamp, Hose
7	W10591540	Adapter, Drain	16	W10591561	Enclosure, Motor	26	W10605800	Sprayarm, Lower
8	W10591562	Chopper Assembly	17	8269144	Hose, Drain	27	W10710432	Shield, Capacitor
9	W10591569	Motor Assembly (Also Order Item 13)	18	W10445975	Hose Assembly (Includes 2 Clamps)			
			19	W10591558	Impeller Assembly			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)	2	W10327455	Sprayarm, Third Level	4	W10571946	Manifold
			3	3400918	Retainer	5	W10605345	Sprayarm, Upper
						6	W10195690	Bracket, Feed Tube


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11188800	Dishrack, Upper	8	W10635042	Handle, Dishrack (Front)
2	W10756567	Cupshelf	9	W10562068	Handle, Dishrack (Rear)
3	W10663572	Mount, Cupshelf	10	W10567728	Track Assembly
4	W10609586	Stabilizer, Rack	11	W10309090	Screw
5		Rack Adjuster	12	9741232	Screw
	W10609579	Left Hand			
	W10609578	Right Hand			
6	W10251047	Cover, Rack Adjuster			
7	W10627763	Lever, Rack Adjuster			

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525641	Dishrack, Lower	3	W10630199	Silverware Basket Assembly	4	W10630198	Lid, Side
2	W10195416	Wheel & Transport Assembly				5	W10630197	Lid, Center

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171657	Black
	8171656	White
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		Handle Assembly
	W10702080	Black
	W10702081	White
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis