



UNDERCOUNTER DISHWASHER


MODELS:

WDF331PAHB1 (Black)

WDF331PAHW1 (White)

WDF331PAHS1 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Panel Front	7	8268961	Sleeve, Friction
	W11380971	Energy Guide		W10274895	Black	8		Fastener
	W11384187	Owners Manual		W10274896	White		W10503548	Black
	W11266092	Tech Sheet		W10274902	Stainless		W10503549	White
2		Arm, Hinge	5		Access Panel	9	W10519755	Insulation, Toe Panel
	W10274922	Left Hand		W10799402	Black	10	489470	Screw
	W10274921	Right Hand		W10799403	White			
3	W10803537	Stiffener, Door	6	W10315897	Insulation, Front Panel			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)	4	W10274884	Bolt, Latch	10	W10350294	Button Tree
	W11043483	Black	5	W10348409	Screw	11	W10350295	Light Pipe
	W11043486	White	6	8524471	Actuator, Latch			
2	W10825638	Box, Connector	7	W10919360	Control, Electronic			
3		Handle, Latch	8	W10825369	Brace, Connector			
	W10716685	Black	9	W10678341	Spring, Latch			
	W10716686	White						


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	5	W10919772	Deflector, Vent (Also Order Item 4)	9	8269296	Seal, Door/Console
2	W10274908	Inner Door (Also Order Item 4)	6	W10671905	Dispenser Assembly	10	W10462232	Bracket, Dispenser
3	W10482094	Cover, Dispenser	7	W10832781	Harness, Wiring	11	W10524920	Cap, Rinse Aid
4	W10254545	Gasket, Vent	8	W10177098	Screw			


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11130744	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10349289	Tub Assembly (Includes Heater Assembly)	11	3400892	Screw	21	W10441445	Heater Element Assembly
2	W10321574	Shield, Thermostat	12	W10831279	Cord, Power			(Includes Heater Washer & Nut)
3	W10524469	Seal, Tub	13	W10866979	Shield, Tub Sound	22	W10732961	Bracket, Heater Support
4	W10341745	Screw	14	W10539489	Clip, Thermostat			NOTE: If heater element is removed, it must be replaced.
5	3400061	Screw	15	3371618	Thermostat	23	W10477552	Nut, Heater Element
6	8269145	Bracket, Undercounter	16	8580309	Strike, Latch			
7	W10304231	Support, Bottom	17	3378128	Washer, Pronged Cup			
8	W10619352	Leveler, Leg	18	3400014	Screw, Grounding			
9	W10337934	Spring, Door Balance	19	8268990	Bushing, Door Spring			
10	8575897	Wheel Assembly	20	W10819539	Sound Insulation, Bottom			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	6	W10372113	Tab, Sump	14	W10169167	Clamp, Hose
2	W10482462	Sump With Seal (Also Order Items 13 & 16)	7	W10789806	Filter Cup Assembly	15	W10195086	Motor, Isolator
3	W10463906	Screen	8	W10724439	Pump, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
4	W10854709	Motor (Also Order Items 13 & 16)	9	8269144	Hose, Drain	17	W10491331	Sprayarm
5	W11184516	Sump & Motor Assembly	10	W10348407	Screw			
			11	370445	Clamp, Hose			
			12	W10723295	Indicator, Optical Wash			
			13	W11182008	Grommet			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10671930	Feed Tube Assembly	3	W10498900	Sprayarm
2	W10165274	Screw	4	W10340681	Manifold


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826745	Dishrack, Upper	4	8565925	Stop, Track (Non-Removable)	6	W10380410	Cupshelf, Small
2	W10845760	Mount, Wheel Assembly	5	W10306228	Track, Spacer	7	W10082861	Stop, Track (Removable)
3	3385089	Track, Dishrack						

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8561705	Dishrack, Lower
2	8268645	Wheel & Transport Assembly
3	8562045	Basket, Silverware (Assembly)

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
		Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis