




SIDE BY SIDE REFRIGERATOR

MODELS:

WRS315SDHW01 (White)
WRS315SDHB01 (Black)
WRS315SDHT01 (Biscuit)
WRS315SDHM01 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	12	W10142234	Screw	27	W10897565	Assembly, Bracket
	W11105301	Use and Care Guide	13	W11093938	Assembly, Bottom Hinge (Freezer)	28	W10179146	Assembly, Filter Valve
	W11248697	Tech Sheet	14	3400113	Screw	29	W11175632	Locking Ring (1/4)
	W11090528	Energy Guide	15	2152958	Screw		W11175631	Locking Ring (5/16)
2		Assembly, Roller	16		Filler, Wrapper	30	W10900449	Tube, Filter Inlet
	W10304660	Left Hand		W11189128	White	31	W10900447	Tube, Filter Outlet
	W10304659	Right Hand		W11189127	Black	32	W10735398	Filter, Water
3	W10141645	Screw		W11189129	Biscuit	33		Housing, Water Filter
4	2150304	Roller		W11189126	Grey		W11036340	White
5	2262072	Axle, Roller	17		Grille		W11036341	Black
6	2155013	Clip, Grille		W10920727	White		W11036339	Biscuit
7	W11036715	Plate, Screw (Refrigerator)		W10920723	Black		W11036338	Grey
	W10904380	Plate, Screw (Freezer)		W10920732	Biscuit	34	W10357076	Tube, Water
8	W11087168	Clip, Roller		W10897568	Grey	35	W10329003	Clamp, Tube
9		Hinge, Top	18	W10308750	Screw (White)	36	2181939	Insert, Tube
	W10922200	White (Refrigerator)		W10308751	Screw (Black)	37	W11091654	Connector, Double Lock
	W10922201	White (Freezer)	19		Cabinet (Not A Servicable Part)	38	W10271541	Connector, Union
	W10922216	Black (Refrigerator)	20	W10905504	Closer, Lower Cam Door (Refrigerator)			
	W10922217	Black (Freezer)	21	489464	Screw			
	W10922218	Biscuit (Refrigerator)	22	2304888	Fitting, Drain			
	W10922219	Biscuit (Freezer)	23	W10153550	Extension, Drain Fitting			
	W10900868	Grey (Refrigerator)	24	W10904634	Cover, Unit			
	W10900869	Grey (Freezer)	25	W11097327	Assembly, Bottom Hinge (Refrigerator)			
10	W11095731	Closer, Door (Freezer)						
11	8281149	Screw	26	549193	Clamp, Power Cord			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	4	1118894	Switch, Rocker Arm	10	W11222026	Tubing, Water Reservoir
2	W10166130	Lens, Light (Includes Gasket)	5	W11162983	Diffuser, Air	11	W10141518	Screw
			6	W11125625	Lamp, LED			
3	W11026017	Assembly, Control Box (Includes Electronic Control)	7	W10384183	Thermistor			
			8	W10900030	Cover, Light			
			9	W10134764	Socket, Light			


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11205398	Assembly, Cover	4	W10173126	Assembly, Shelf Stud	6	W11135529	Assembly, Shelf
2	W11046494	Pan, Crisper	5	W10191954	Screw	7	W10904001	Holder, Pan
3	W11046495	Pan, Meat						


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W10130299	Cup, Shelf	15	2196206	Stud, Support
2	W10318948	Shelf, Wire	8	W10191954	Screw	16	W10845583	Slide, Ice Container (Right)
3	W10134764	Socket, Light	9	2196208	Assembly, Stud		W10845585	Slide, Ice Container (Left)
4	1115373	Switch, Rocker Arm (Freezer)	10	W10318961	Shelf, Wire	17	489100	Screw
5	W10318947	Shelf, Wire	11	W11125625	Lamp, LED			
6	2309757	Bin, Freezer	12	2315163	Clip, Air Duct			
			13	3400893	Screw			
			14	2171706	Lens, Light			


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11210541	Bracket, Motor	16	W10278733	Blade, Rotary C	32	489236	Ring, Retainer
2	W10884561	Motor, Dispenser	17	489234	Washer, Plain Upper Cam	33	W10698668	Coupling, Ice Conveyor
3	2152713	Assembly, Solenoid	18	W10181990	Blade, Fixed	34	W10300022	Assembly, Ice maker
4	2171706	Lens, Light	19	W10189708	Block, Blade	35	W10508644	Harness, Ice maker
5	W10138206	Spacer - Crusher Housing	20	489229	Pin, Roll	36	W10512602	Arm, Shut Off
6	W11082352	Assembly, Ice Dispenser Wiring	21	W10295082	Auger	37	W10289690	Cover, Ice maker
7	489399	Screw	22	W10698642	Drum	100	W10558423	Ice Container, Complete
8	W10169511	Coupling, Motor	23	W10403781	Baffle, Floating			
9	W10189191	Cover, Ice Container Front	24	1119018	Nut, Bearing			
10	W10189202	Ice Door	25	W10838981	Arm, Control			
11	W10670845	Container, Ice	26	1119020	Spring, Return			
12	W11032812	Spacer, Step	27	1119021	Clip, Retainer (Dispenser Rod)			
13	W11032808	Spacer, Flat	28	488886	Screw			
14	W10278731	Blade, Rotary A	29	W10185018	Housing, Crusher			
15	W10278732	Blade, Rotary B	30	1119017	Deflector, Ice			
			31	489234	Washer, Plain Upper Cam			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Door Gasket)	5		Handle	13	W10142283	Screw (White)
	W10912118	White		W11045527	White		W10308487	Screw (Black)
	W10912126	Black		W11045528	Black		W10308489	Screw (Grey)
	W10912135	Biscuit		W11031875	Biscuit	14		Bumper, Door
	W11258450	Stainless		W11045530	Stainless		W10407175	White
2	2256101	Door, Compartment	6	2200087	Thimble		W10407187	Black
3	W10900538	Bin, Door	7	2309941	Trivet		W10407203	Biscuit
4		Gasket, Door	8	W10900464	Thimble, Cam		W10407188	Grey
	W10912123	Beige	9	489420	Screw			
	W10912133	Black	10		Bracket, Door Stop			
	W10912081	Grey		W10900463	Black			
			11	W10884773	Badge			
			12	W10460893	Screw			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Gasket and Dispenser Parts)	2		Handle	6	2309718	Trivet
	W11025560	White		W11045527	White	7	W10296804	Screw
	W11025561	Black		W11045528	Black	8		Gasket, Door
	W11025562	Biscuit		W11031875	Biscuit		W10911412	Beige
	W11258444	Stainless		W11045530	Stainless		W10911422	Black
			3	2200087	Thimble		W10911389	Grey
			4		Bracket, Door Stop	9	W10900532	Thimble, Cam
				W10900531	Black	10	W10460893	Screw
			5	W10296816	Screw	11	W10307494	Trim, Door Shelf


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W11039857	Retainer, Separator Hose	7	W10898319	Harness, Wire
2		Assembly, User Interface (Includes Light Feature)	6		Front Cover, Dispenser	8	8281163	Screw (Stainless)
	W10898320	Black		W11032325	White (Left Hand)			
	W10922070	Desert Sparkle		W11032331	White (Right Hand)			
3	W10898317	Assembly, Water Fitting		W11032324	Black (Left Hand)			
				W11032326	Black (Right Hand)			
4		Assembly, Separator		W11032323	Biscuit (Left Hand)			
	W11024787	White		W11032330	Biscuit (Right Hand)			
	W11024786	Black						
	W11024788	Biscuit						
	W11024790	Neptune Frost						


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11228713	Scroll, Fan	6	W10252477	Gasket, Air Duct	12	W10911770	Harness, Evaporator Fan (Includes Thermal Fuse)
2	W10188846	Retainer, Fan Motor	7	2315549	Motor, Fan	13	2155789	Gasket
3	489478	Screw	8	2169142	Blade, Fan	14	W10463013	Cover, Evaporator
4		Support, Fan Scroll	9	2304241	Gasket			
	2203596	Left Hand	10	2176759	Grommet, Motor			
	2203595	Right Hand	11	W10142292	Screw			
5	W11110658	Duct, Freezer Air						

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10174384	Strap, Bale	19	W10897557	Tray, Evaporator	35	489478	Screw
2	2225834	Blade, Fan	20	W10194475	Assembly, Heat Shield and Drain Pan	36	2169104	Insulation, Sound Deadening
3	W10904626	Assembly, Condenser	21	W10771114	Drier	37	W11189542	Assembly, Precooler Formed
4	W10900442	Rail, Unit Mounting	22	489473	Screw			FOLLOWING PARTS NOT ILLUSTRATED
5	489396	Clip	23	W10900446	Frame, Unit Mounting (Includes Unit Mounting Rail)			
6	8533993	Screw					978025	Valve, Access (1/4")
7	W10670169	Assembly, Unit Wire (Includes Power Cord)	24	489464	Screw		978026	Valve, Access (5/16")
8	2161302	Sleeve	25	2181929	Bracket, Fan Mounting		978027	Valve, Access (3/8")
9	489427	Screw	26	2188175	Heater, Defrost		978029	Valve, Access (5/8")
10	W11183387	Tube, Suction	27	2161324	Clip, Defrost Heater		978030	Valve, Access (3/4")
11	2311725	Clip, Condenser	28	W10879296	Compressor		876764	Valve, Access (3/16")
12	W10350564	Capacitor	29	W10836504	Grommet, Compressor			REFRIGERANT CHARGE
13	W11239207	Tube, Process	30	489340	Bolt			5.5 oz (R-134A)
14	W10197428	Device, Combination Start (Start Relay and Overload)	31	W10897567	Baffle, Air			
15	8281232	Screw	32	2263990	Tie, Wire			
16	2188823	Evaporator	33	W10897560	Assembly, Unit Cover (Bottom)			
17	2161324	Clip, Defrost Heater	34	W10895163	Probe, Heat			
18	W10522629	Motor, Condenser Fan						

OPTIONAL PARTS

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet
	W10300794	Kit, Handle Installation
	W10715708	Ice Maker Assembly (ECKMF95)

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key