



SIDE BY SIDE REFRIGERATOR

MODELS:


WRS325SDHW01 (White)

WRS325SDHB01 (Black)

WRS325SDHV01 (Black Stainless)

WRS325SDHZ01 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	3400113	Screw	30	W11095731	Closer, Door (Freezer)
	W11105301	Use and Care Guide	15		Assembly, Roller	31	W10142234	Screw
	W11212322	Tech Sheet		W10304659	Right Hand	32		Housing, Water Filter
	W11090507	Energy Guide	16		Filler, Wrapper		W11036340	White
2		Assembly, Roller		W11189128	White		W11036341	Black
	W10304660	Left Hand		W11189127	Black		W11036338	Grey
3	2152958	Screw		W11189126	Grey	33		Cabinet (Not A Servicable Part)
4	2150304	Roller	17		Grille			
5	2262072	Axle, Roller		W11226340	White	34	W10897565	Assembly, Bracket
6	2155013	Clip, Grille		W11226342	Black	35	W11175632	Locking Ring (1/4)
7	W11036715	Plate, Screw (Refrigerator)		W11226338	Grey		W11175631	Locking Ring (5/16)
	W10904380	Plate, Screw (Freezer)	18	W10308750	Screw (White)		W10905504	Closer, Lower Cam Door (Refrigerator)
8	W11087168	Clip, Roller		W10308751	Screw (Black)			
9		Hinge, Top	19	W11091654	Connector, Double Lock	36		
	W10922200	White (Refrigerator)	20	489290	Screw	37	W10357076	Tube, Water
	W10922201	White (Freezer)	21	489464	Screw	38	W10179146	Assembly, Filter Valve
	W10922216	Black (Refrigerator)	22	2304888	Fitting, Drain	39	2209774	Chute, Water
	W10922217	Black (Freezer)	23	W10153550	Extension, Drain Fitting	40	W10329003	Clamp, Tube
	W10900868	Grey (Refrigerator)				41	2181939	Insert, Tube
	W10900869	Grey (Freezer)	24	W10904634	Cover, Unit			
10	489500	Screw	25	W11097327	Assembly, Bottom Hinge (Refrigerator)			
11	8281149	Screw	26	W10900449	Tube, Filter Inlet			
12	W10900447	Tube, Filter Outlet	27	W10735398	Filter, Water			
13	W11093938	Assembly, Bottom Hinge (Freezer)	28	549193	Clamp, Power Cord			
			29	W10141645	Screw			





REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	4	W10141518	Screw	9	W10134764	Socket, Light
2	W10166130	Lens, Light (Includes Gasket)	5	W11204060	Assembly, Air Diffuser	10	1118894	Switch, Rocker Arm
3	W11222026	Tubing, Water Reservoir	6	W11048608	Cover, Air Diffuser	11	W10384183	Thermistor
			7	W11125625	Lamp, LED			
			8	W10900030	Cover, Light			


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11205398	Assembly, Cover	5	W10191954	Screw	9	W10904001	Holder, Pan
2	W11046494	Pan, Crisper	6	W11046493	Pan, Snack	10	W10912335	Holder, Snack Pan
3	W11046495	Pan, Meat	7	W11166552	Cover, Snack			
4	W10173126	Assembly, Shelf Stud	8	W11135529	Assembly, Shelf			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	W10191954	Screw	14	3400893	Screw
2	W11048567	Shelf, Glass	9	2196208	Assembly, Stud	15	W10134764	Socket, Light
3	2196206	Stud, Support	10	W11048571	Shelf, Glass (Top)	16	W11125625	Lamp, LED
4	1115373	Switch, Rocker Arm (Freezer)	11	489100	Screw	17	W10384183	Thermistor
5	W11252833	Shelf, Glass (Bottom)	12	2315163	Clip, Air Duct			
6	2309757	Bin, Freezer	13	W10845585	Slide, Ice Container (Left)			
7	W10130299	Cup, Shelf		W10845583	Slide, Ice Container (Right)			


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11210541	Bracket, Motor	16	W10278733	Blade, Rotary C	32	489236	Ring, Retainer
2	W10884561	Motor, Dispenser	17	489234	Washer, Plain Upper Cam	33	W10698668	Coupling, Ice Conveyor
3	2152713	Assembly, Solenoid	18	W10181990	Blade, Fixed	34	W10300022	Assembly, Icemaker
4	W11204001	Lens, Light	19	W10189708	Block, Blade	35	W10289690	Cover, Icemaker
5	W10138206	Spacer - Crusher Housing	20	489229	Pin, Roll	36	W11182354	Assembly, Shut Off Arm
6	W11218402	Assembly, Ice Dispenser Wiring	21	W10295082	Auger	37	W10508644	Harness, Icemaker
7	489399	Screw	22	W10698642	Drum	38	628320	Bracket, Icemaker Mounting
8	W10169511	Coupling, Motor	23	W10403781	Baffle, Floating	39	489478	Screw
9	W10189191	Cover, Ice Container Front	24	1119018	Nut, Bearing	100	W10558423	Ice Container, Complete
10	W10189202	Ice Door	25	W10838981	Arm, Control			
11	W10670845	Container, Ice	26	1119020	Spring, Return			
12	W11032812	Spacer, Step	27	1119021	Clip, Retainer (Dispenser Rod)			
13	W11032808	Spacer, Flat	28	488886	Screw			
14	W10278731	Blade, Rotary A	29	W10185018	Housing, Crusher			
15	W10278732	Blade, Rotary B	30	1119017	Deflector, Ice			
			31	489234	Washer, Plain Upper Cam			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Includes Door Gasket)	5		Handle	12	W10460893	Screw
	W10912118	White		W11045527	White	13	3400012	Screw
	W10912126	Black		W11045528	Black	14	W11034218	Rack, Can
	W10912320	Black Stainless		W11045529	Black Stainless	15		Bumper, Door
	W10912110	Stainless		W11045530	Stainless		W10407175	White
2	2256101	Door, Compartment	6	2200087	Thimble		W10407187	Black
3	W10900538	Bin, Door	7	2309941	Trivet		W10407188	Grey
4		Gasket, Door	8	W10900464	Thimble, Cam			
	W10912123	Beige	9	W10142283	Screw (White)			
	W10912133	Black		W10308487	Screw (Black)			
	W10912081	Grey		W10308489	Screw (Grey)			
			10		Bracket, Door Stop			
				W10900463	Black			
			11	W10884773	Badge			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Item 8)	4		Bracket, Door Stop	12		Bumper, Door
	W11026363	White		W10900531	Black		W10407175	White
	W11026364	Black	5	W10296816	Screw		W10407187	Black
	W11026362	Black Stainless	6	2309718	Trivet		W10407188	Grey
	W10913113	Stainless	7	W10296804	Screw			
2		Handle	8		Gasket, Door			
	W11045527	White		W10911412	Beige			
	W11045528	Black		W10911422	Black			
	W11045529	Black Stainless		W10911389	Grey			
	W11045530	Stainless	9	W10307494	Trim, Door Shelf			
3	2200087	Thimble	10	W10460893	Screw			
			11	W10900532	Thimble, Cam			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5		Assembly, User Interface (Includes Light Feature)	7		Cover, Dispenser Front
2	W10913117	Harness, Wire		W11169239	Black		W11183318	White (Left Hand)
3	W10898317	Assembly, Water Fitting	6	W11039857	Retainer, Separator Hose		W11183314	White (Right Hand)
4		Assembly, Separator					W11183317	Black (Left Hand)
	W11231386	White					W11183313	Black (Right Hand)
	W11231385	Black				8	8281163	Screw (Stainless)
	W11231384	Grey						


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11228713	Scroll, Fan	6	W10252477	Gasket, Air Duct	12	W10911770	Harness, Evaporator Fan (Includes Thermal Fuse)
2	W10188846	Retainer, Fan Motor	7	2315549	Motor, Fan	13	2155789	Gasket
3	489478	Screw	8	2169142	Blade, Fan	14	W10463013	Cover, Evaporator
4		Support, Fan Scroll	9	2304241	Gasket			
	2203596	Left Hand	10	2176759	Grommet, Motor			
	2203595	Right Hand	11	W10142292	Screw			
5	W11110658	Duct, Freezer Air						

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10174384	Strap, Bale	21	489340	Bolt	37	2323186	Box, Control
2	2225834	Blade, Fan	22	W10897560	Assembly, Unit Cover (Bottom)	38	W11133692	Control, Electronic
3	W10904626	Assembly, Condenser	23	W10900446	Frame, Unit Mounting (Includes Unit Mounting Rail)	39	W11228998	Assembly, Unit Wire
4	W10900442	Rail, Unit Mounting	24	8533859	Screw	40	W10895163	Probe, Heat
5	2326941	Clip, Wire	25	2181929	Bracket, Fan Mounting	41	489478	Screw
6	8533993	Screw	26	2188175	Heater, Defrost	42	W11189542	Assembly, Precooler Formed
7	W10271541	Connector, Union	27	2161324	Clip, Defrost Heater	43	2169104	Insulation, Sound Deadening
8	2161302	Sleeve	28	W11322225	Compressor			FOLLOWING PARTS NOT ILLUSTRATED
9	489427	Screw	29	W10836504	Grommet, Compressor	978025		Valve, Access (1/4")
10	W11183387	Tube, Suction	30	W10771114	Drier	978026		Valve, Access (5/16")
11	2311725	Clip, Condenser	31	W10197428	Device, Combination Start (Start Relay and Overload)	978027		Valve, Access (3/8")
12	2263990	Tie, Wire	32	W10350564	Capacitor	978029		Valve, Access (5/8")
13	W11239207	Tube, Process	33	489473	Screw	978030		Valve, Access (3/4")
14	W10897567	Baffle, Air	34	489396	Clip	876764		Valve, Access (3/16")
15	8281232	Screw	35	489464	Screw			REFRIGERANT CHARGE
16	2188823	Evaporator	36	W10334855	Cover, Control			5.5 oz (R-134A)
17	2161324	Clip, Defrost Heater						
18	W10522629	Motor, Condenser Fan						
19	W10897557	Tray, Evaporator						
20	W10194475	Assembly, Heat Shield and Drain Pan						

OPTIONAL PARTS

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350939	Enamel, Black
	350930	White
	4392901	Biscuit/Bisque

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet
	W10300794	Kit, Handle Installation
	W10715708	Ice Maker Assembly (ECKMF95)

TORX SCREW WRENCH

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key