



FOUR DOOR BOTTOM MOUNT REFRIGERATOR


MODELS:

WRX735SDHW01 (White)

WRX735SDHB01 (Black)

WRX735SDHV01 (Black Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	12992403	Screw	26		Cabinet (Not A Servicable Part)
	W10873263	Tech Sheet	15		Hinge, Center Left Hand	27	W10867574	Control, Electronic
	W11298856	Use & Care Guide		W10740148	White	28	688983	Screw
	W11308947	Energy Guide		W10740149	Black	29	W10914798	Gasket, Control Box
2	12961401	Tube, Water	16		Hinge, Center Right Hand	30	W10270394	Cover, Unit
3	12698403	Plate, Pivot		W10740144	White	31	W10141622	Brake, Roller
4	B5759655	Gasket		W10740145	Black	32	M0104106	Clip, Cord
5		Cover, Top Hinge Left Hand	17		Cover, Corner	33		Assembly, Roller
	W10337634	White		12587703W	White		W10515763	Left Hand
	W10337647	Black		12587703B	Black		W10515762	Right Hand
6		Cover, Top Hinge Right Hand	18	W10827867	Knob, Vent Slide	34		Assembly, Secondary Mullion
	12962302W	White	19	A3076901	Plug, Button		W10902088	White
	12962302B	Black	20	W10709365	Screw		W10902087	Black
7	12961602	Cover, Control Box	21		Shim, Top Hinge Left Hand	35	W10843353	Assembly, LED Light Module
8	M0108107	Clamp, Tube		12999502	Right Hand	36	W10820998	Housing, Module
9	12992602	Screw	22		Grille, Toe	37	W10492234	Brace, Mullion
10		Hinge, Top		W10534154	White	38	W11097348	Mullion, Secondary
	12963204ED	Left Hand		W10534153	Black	39		Cover, Fill Tube
	12963205ED	Right Hand	23	W10296541	Lid, HV Control Box		12981401W	White
11	W10673840	Screw (Stainless)	24	W10316401	Wedge, Spacer (Left Hand & Right Hand)		12981401B	Black
12	12990511	Screw	25	12990702	Screw	40	W10367522	Slide, Mullion Vent
13	W10316403	Wedge, Spacer (Left Hand & Right Hand)						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	9	W10118193	Enclosure, Water Valve Connector	16	W10309869	Cover, Wiring
2	3400065	Screw (Stainless)	10	W10444033	Tube, Water	17	W10334463	Bracket, Water Tank and Valve
3	W11245960	Lens, LED	11	12960101	Cover, Upper Water Tank	18	W11308017	Assembly, Water Tank and Head (Includes Bypass Cartridge)
4	W11101384	Module, LED Light	12	12960301	Cover, Filter	19	12664501SP	Cartridge, Bypass
5	W10555984	Assembly, Air Grille	13	12960001	Cover, Lower Water Tank			
6	W10847848	Switch, Rocker	14	W11256384	Filter, Water			
7	W10118194	Lid, Enclosure	15	12955901	Bracket, Filter Base			
8	W10913947	Valve, Water Inlet						


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13		Bracket, Door Slide	23	12951401	Shroud, Evaporator
2	A3189392	Gasket, Foam		W10330991	Left Hand	24	12986101	Blade, Fan
3	12002497	Gear		W10330993	Right Hand	25	W10905511	Grommet, Fan Motor
4	12990501	Screw	14	W10315248	Module, Light	26	W11050039	Motor, Evaporator (Includes Heater Harness and Defrost Thermostat)
5	W10802332	Shaft, Rack	15	12956601	Clip, Fan Motor			
6	M0500703	Seal	16	12466111SP	Switch, Light			
7	12815301	Cover, Thermistor	17	12990504	Screw	27	W10662407	Assembly, Drain Funnel
8	12990521	Screw	18	B8381501	Gasket, Drain			
9	W11251749	Light Module, LED	19	W10860513	Slide, Door			
10	12791417SP	Thermistor	20	A3189396	Gasket			
11	W10308421	Cover, Evaporator	21		Adapter, Side			
12	12990511	Screw		W10284682	Left Hand			
				W10284683	Right Hand			
			22	12959901	Grille, Air			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	8		Gasket, Door	15		Stop, Door
		Left Hand		W10830276	White		12968202W	White
	13107323W	White		W10830277	Black		12968202B	Black
	13107323B	Black	9		Handle, Door	16	12996601	Clip, Bushing
	W11022747	Black Stainless		W11115760	White	17		Latch, Door Closer
2		Door, Refrigerator		W11115759	Black			Right Hand
		Right Hand		W10918272	Black Stainless		W10833738	White
	13107319W	White	10	W10884773	Badge		W10725267	Black
	13107319B	Black	11	W10511930	Waterline, Door	18		Latch, Door Closer
	W11022757	Black Stainless	12	W10287601	Seal, Ice Chute			Left Hand
3	W10355270	Bucket, Small	13		Mullion, Door		W10833740	White
4	12990521	Screw		W10311759	White		W10725268	Black
5	W10355264	Bucket, Gallon		W10311758	Black	19	W10355269	Bucket, Upper
6	12990513	Screw	14		Closure, Door			
7	W10460893	Screw		12028505W	White			
				12028505B	Black			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	6	W10146439	Divider, Upper Basket	10		Bracket, Door Slide
	W11023065	White	7		Gear		W10330991	Left Hand
	W11023033	Black		W10474716	Left Hand		W10330993	Right Hand
	W10920749	Black Stainless		W10474715	Right Hand	11		Handle, Door
2		Gasket, Door	8		Rack, Side		W11101978	White
	W10443321	White		W10516603	Left Hand		W11101980	Black
	W10436253	Black		W10516602	Right Hand		W11101977	Black Stainless
3	W10293682	Bin, Lower	9		Mount, Gear	12	W10460893	Screw
4	W10802333	Shaft, Rack		W10348259	Left Hand			
5	W11115237	Basket, Upper		W10348260	Right Hand			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	18	W10346415	Condenser	34	W10334458	Connector, Water Tube
2	12825803	Blade, Fan	19	W10281329	Clip, Drier	35	W10815863	Clip, Condenser
3	W10480111	Basepan	20	W10292803	Tray, Drip			FOLLOWING PARTS NOT ILLUSTRATED
4	12990511	Screw	21	12990702	Screw			
5	2319835	Grommet, Condenser	22	W10313899	Evaporator		978025	Valve, Access (1/4")
6	W10795418	Tube, Discharge	23	A3189397	Gasket, Foam		978026	Valve, Access (5/16")
7	2169104	Insulation, Sound Deadening	24	W10909377	Motor, Condenser Fan		978027	Valve, Access (3/8")
8	W10655368	Pan, Drain	25	10428101	Clip, Heater		978029	Valve, Access (5/8")
9	W10622701	Screw	26	W11239039	Harness, Unit (Includes Power Cord)		978030	Valve, Access (3/4")
10	12729123	Heater, Defrost	27	W10177049	Drier		876764	Valve, Access (3/16")
11	W10798748	Device, Start	28	W11100924	Compressor			REFRIGERANT CHARGE
12	W10216075	Strap, Bale	29	10623002	Clip, Evaporator			4.50 oz. (R-134A)
13	W10137529	Grommet, Condenser	30	12477202	Axle, Roller			
14	W10622099	Extension, Drain Tube	31	W10189184	Shroud, Condenser Fan			
15	12477102	Roller	32	W10350564	Capacitor			
16	12992101	Screw	33	W10236396	Strap, Compressor			
17	W10806346	Grommet, Compressor						

SHELF PARTS




SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11124652	Assembly, Shelf and Roller
2		Runner, Roller
	W10346891	Left Hand
	W10346890	Right Hand
3	8281136	Screw
4	W10366647	Pan, Deli
5	W10396909	Front, Deli Pan
6	W11156814	Shelf, Mini
7		Door, Pantry
	W11023061	White
	W10921835	Black
	W10920753	Black Stainless
8		Gasket, Pantry
	W10443325	White
	W10436255	Black
9	W11117039	Shelf, Stationary

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10		Adapter, Pantry
	W11093713	Left Hand
	W11093714	Right Hand
11	W10277360	Gear, Spur
12		Cover, Gear
	W10284709	Left Hand
	W10294414	Right Hand
13	W10272364	Screw
14	W10460893	Screw
15	W10802341	Shaft, Rack
16		Ladder, Side
	W10251968	Left Hand
	W10251965	Right Hand
17	W10277361	Collar, Gear
18	W10801677	Pan, Pantry
19	W10273464	Ladder, Center

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20		Handle, Door
	W11101978	White
	W11101980	Black
	W11101977	Black Stainless
21	12990513	Screw
22	12990512	Screw
23	W10818644	Divider, Pantry
24	W10296571	Glass, Pantry Shelf
25	W10847852	Switch, Rocker
26		Rail, Pantry
	W10311723	Left Hand
	W10311726	Right Hand
27	W11048306	Runner, Channel
28	W10331298	Rail, Rear Pantry
29	12990521	Screw
30		Cover, Pantry Rail
	W10311725	Left Hand


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	4		Assembly, Pad (Includes Blue Light)	8	W10339578	Guide, Ice
2		Assembly, User Interface		W10353846	White	9		Dispenser, Tray
	W11114473	Silver		W10353847	Black		W11045970	White
3		Wall, Dispenser False	5	W10238083	Assembly, LED		W11045971	Black
	W11045975	White	6	W10353552	Assembly, Separator (Includes Spigot and Ice Guide)	10	W11045974	Black Stainless
	W11045976	Black						Tray, Dispenser Slide
	W11045979	Black Stainless	7	2316647	Assembly, Spigot Body		W10267860	White
							W10267861	Black
						11	W10254277	Cover, Board

ICEMAKER & ICE CONTAINER PARTS



ICEMAKER & ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11097357	Assembly, Ice Bin	10	W10317991	Motor, Dispenser	19	W10300024	Assembly, Icemaker (Complete)
2	W10121282	Inlet, Blower	11	W10196393	Damper, Control	20	W11130404	Arm, Shutoff
3	W10309863	Scroll, Blower	12	W10309866	Assembly, Solenoid	21	W10351019	Extension, Shutoff Arm
4	W10308033	Motor, Fan	13	W10118612	Liner, Divider	22	W10290556	Cover
5	W10123444	Wheel, Blower	14	12990511	Screw	23	W10826037	Harness, Icemaker
6	12956603	Clip, Fan Motor	15	W10346971	Bracket, Solenoid	24	12791417SP	Thermistor
7	W10151687	Grommet, Fan Motor	16	W10465946	Washer			
8	W10309864	Divider, Ice Box	17	63052A001	Yoke, Ice Dispenser			
9	12920001	Gasket, Damper	18	W10312691	Assembly, Impinger			

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet
	IC13B	Icemaker Kit

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key