




按阿凡提62L全气做系列面板

G2404CW

Number	Part Name	Part Code#	Quantity	Number	Part Name	Quantity	Part Code#
1	Power Cord	TO-DYX0012	1	58	Pad of Glass	4	
2	Clamp for Power Cord	TOTYSL00004	1	59	Door Seal for Inner Glass	1	
3	Small Rear Plate		1	60	Door Glass	1	TOTYBL00184
4	Backplate of Backsplash	TO76CY00067	1	61	Handle connecting Bracket	4	
5	Outer Backplate	TO76CY00066	1	62	Door Handle	1	
6	Backsplah	TO76FW00061	1	63	Bottom Door Liner	1	TO62FW00110
7	Rear Oven Insulation		1	64	Drawer Handle	1	
8	Oven enclosure insulation		1	65	Drawer Panel	1	TO76FW00034
9	Igniter Module	TO62DQ00132	1	66	Drawer Board	1	TO76FW00035
10	Lamp Holder		1	67	Drawer Bracket	1	TO76CY00001
11	Lamp	TO62DQ00077	1	68	Left Drawer Bracket	1	
12	Lamp Lens		1	69	Drawer Body	1	TO76FW00038
13	Smoke Cover		1	70	Right Drawer Bracket	1	
14	Burner Connector		2	71	Rear Drawer Board	1	
15	Connector Bracket		1	72	Left Drawer Slide	1	TO62SL00001
16	Nozzle		2	73	Right Drawer Slide	1	TO62SL00002
17	M12 Bolt		2	74	Inner Glass	1	
18	Thermostat Folder		1	75	Gasket Connecting Piece	1	TO62CY00018
19	Cooktop	TO76FW00032	1	76	Door Seal	1	TO76SL00006
20	Burner Grate	TO76WJ00064	1	77	Door Seal Hook	4	TO62CY00017
21	Burner Assembly (medium)	TO62DQ00065	2	78	Door Hinge fixing Plate	2	
22	Burner Assembly (small)	TO62DQ00064	1	79	Oven Burner Cover liner	1	TO76FW00059
23	Burner Assembly (Large)	TO62DQ00066	1	80	Under the Board liner	1	TO76FW00060
24	Top Burner Igniter	TO62DQ00070	4	81	Lower Burner (Bake)	1	TO62CY00061
25	Burner Grate	TO76WJ00064	1	82	Lower Bake Burner Support	1	
26	Burner Bracket		2	83	Oven Thermocouple (1300)	1	TO62DQ00074
27	Gas Connection Tube		2	83a	Broil Thermocouple (900)	1	TO62DQ00073
28	Connection Tubes		4	84	Oven Igniter (1260)	1	TO62DQ00072
29	Left Panel	TO62FW00106	1	84a	Broil Igniter (900)	1	TO62DQ00071
30	Left Panel Trim	TO62FW00108	1	85	Middle Separating panel	1	TO76CY00021
31	Broiler Grid	TO76FW00003	1	86	Oven Drawer Slide plate	1	TO76CY00006
32	Broiler Pan	TO76FW00002 / Z-E62A-33(T)	1	87	Drawer Slide	2	TO62SL00003
33	Wire Rack	TO76WJ00001 / Z-E76A.67	1	88	Drawer mounting plate	1	TO76CY00005
34	On the Partition		1	89	Bottom Bracket	1	
35	Rear Panel of Inner Liner	TO76FW00057	1	90	Adjustable feet	4	TO62SL00004
36	Top Panel of Inner Liner	TO76FW00058	1	91	Bottom Bracket angle	8	
37	Upper Burner Fixing Support		1	92	Bottom Bracket Fixing piece	1	TO62FW00017
38	Side Pane of Inner Liner	TO62FW00129	2	93	Right Panel Trim	1	TO62FW00109
39	Inner Front Panel	TO76FW00056	1	94	Right side panel	1	TO62FW00107
40	Upper Burner (Broil)	TO62CY00060	1	95	Oven Valve	1	
41	Control Panel	TO76FW00033	1	96	Oven Valve clip	1	
42	Clamp for Cooktop		2	97	Oven Burner Valve	4	TO62DQ00057
43	Switch	TO62DQ00058	1	98	Clips	4	
44	Knob Socket	TO62SL00041	5	99	Gas Inlet Connector (adapter)	1	
45	Spring for Knob		5	100	Oven Gas Connector 2	1	TO62WJ00088
46	Knob Handle		5	101	Regulator valve	1	TO62DQ00056
47	Clamp for Glass	TO62CY00016	2	102	Oven Gas Connector 1	1	TO62WJ00087
48	Washer for Glass	TO76SL00001	1	103	Bracket for Gas Extention Pipe	1	TO62CY00110
49	Door Seal		1	104	Gas Extention Pipe	1	TO62WJ00110
50	Nut Block	TO62CY00020	2	105	Washer	3	TO62WJ00094
51	Door	TO76FW00004	1	106	Gas Inlet tube	1	TO76WJ00060
52	Door Glass Mat	TO62SL00015	2	107	Micro Switch	1	TO62DQ00058
53	Door Hinge	TO62WJ00008	2	108	Micro Switch Bracket	1	
54	Insulation on the Door		1	109	Bracket	1	
55	Door side insulation		2	110	Bracket for Gas Inlet Valve	1	
56	Right Glass Bracket	TO62CY00015	1	111	Oven Fixed Block	2	
57	Left Glass Bracket	TO62CY00014	1	112	Inside Back Panel	1	TO76CY00011