


Microwave

FFCT1278L S

Featuring Effortless™ Convection



Signature Features

Effortless™ Convection Oven Options

Bake and brown your favorite foods in your microwave oven at the touch of a button—ten preset options allow you to heat from 100 to 450 degrees.

Effortless™ Convection and Microwave Option

Combine the speed and freshness of microwave cooking with the browning capabilities of a convection oven—all with a simple one-touch button.

Effortless™ Grill Oven Options

Allows you to choose between different levels of broiling—top only or top and bottom.

Easy-Set™ Start

Quickly start cooking—one to six minutes—with just one touch.

Countertop

Product Dimensions

Height	13-5/8"
Width	22"
Depth	20-13/16"

More Easy-To-Use Features

Ready-Select™ Controls

Easily select options with the touch of a button.

Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

Effortless™ Reheat

Reheat almost anything at the touch of a button.

Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

Control Lock Option

Electronic Clock/Timer

Helps you keep track of cook times.

Attractive Stainless Steel Exterior

Interior Light

Illuminates the contents of the microwave for increased visibility.

Large Glass Turntable


Even large items fit on our large glass turntable.

Available in:



Stainless
(S)

Features	
Control/Timing System	Ready-Select™
Exterior Door Finish	Stainless Steel
Handle Design	Push Button
Microwave Features	
Microwave Capacity (Cu.Ft.)	1.2
Convection	Yes
Watts (IEC-705 Test Procedure)	1,100/1,500
Interior Light	Yes
Interior Color	White
Turntable Diameter	13-5/8"
Turntable On/Off	Yes
Control Lock	Yes
Clock	Yes
Touch Pad Buttons	26
Power Levels	10
Accessory Metal Rack	Yes
Microwave Control Options	
Easy-Set™ Start	Yes
Popcorn Button	Yes
Chicken Nugget Button	Yes
Baked Potato Button	Yes
Sensor Reheat Button	
Snack Button	
Beverage	Yes
Melt & Soften Options	
Auto Reheat Options	7
Snack Menu Options	
Auto Cook Options	7
Auto Defrost Options	Yes
Keep Warm	Yes
Add-30-Seconds	Yes
Sensor Cooking Options	
Vegetable Cook Sensor	
Delay Start	
User Preferences	
Power Ratings	
Frequency (Mhz)	2,450
Watts @ 120 Volts	1,000
Amps @ 120 Volts	15
Specifications	
Oven Interior Height	9-11/16"
Oven Interior Width	14-1/8"
Oven Interior Depth	14-13/16"
Power Supply Connection Location	Rear
Voltage Rating	120V / 60Hz / 15A
Minimum Circuit Required (Amps)	15
Shipping Weight (Approx.)	51



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at frigidaire.com.



Product Dimensions¹	
A - Height	13-5/8"
B - Width	22"
C - Depth	20-13/16"

¹A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at frigidaire.com

FRIGIDAIRE

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • frigidaire.com
 CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • frigidaire.ca

FFCT1278L 08/10

© 2010 Electrolux Home Products, Inc.

Specifications subject to change.
 Printed in the U.S.A.